



Tool holder spring clamp

Description	Article
Springclamp Terry clamp.area Ø 28-32MM	14594993
Springclamp Terry clamp.area Ø 51-54MM	14594996
Springclamp Terry clamp.area Ø 19-21MM	14594981
Springclamp Terry clamp.area Ø 13-14MM	14594979
Springclamp Terry clamp.area Ø 16-19MM	14594980
Springclamp Terry clamp.area Ø 38-40MM	14594995
Springclamp Terry clamp.area Ø 10-12MM	14594978
Springclamp Terry clamp.area Ø 32-34MM	14594994
Springclamp Terry clamp.area Ø 6-7MM	14594977
Springclamp Terry clamp.area Ø 25-27MM	14594982

Disclaimer: The content of this document has been composed with the utmost care. However, it is possible that certain information changes over time, becomes inaccurate or incomplete. ERIKS does not guarantee that the information provided on this document is up to date, accurate and complete; the information provided is not intended to be advice. ERIKS shall never be liable for damage resulting from the use of the information provided.