



FESTO Sub-Base VMPAL

Sub-bases for MPA-L

Characteristics

Series: VMPAL

Description	Article
Sub-base VMPAL-AP-10 554311	12264667
Sub-base VMPAL-AP-10-QS1/4"-1 560999	14164248
Sub-base VMPAL-AP-10-QS1/4"-1-T1 561023	14164247
Sub-base VMPAL-AP-10-QS1/4"-2 561000	14164255
Sub-base VMPAL-AP-10-QS1/4"-2-T1 561024	14164254
Sub-base VMPAL-AP-10-QS4-1 560994	14164251
Sub-base VMPAL-AP-10-QS4-1-T1 561017	12265238
Sub-base VMPAL-AP-10-QS4-2 560988	14164252
Sub-base VMPAL-AP-10-QS4-2-T1 561018	12265239
Sub-base VMPAL-AP-10-QS6-1 560987	14164246
Sub-base VMPAL-AP-10-QS6-1-T1 561011	14164244
Sub-base VMPAL-AP-10-QS6-2 560993	14164245
Sub-base VMPAL-AP-10-QS6-2-T1 561012	12265237
Sub-base VMPAL-AP-10-RV 8035230	14086224
Sub-base VMPAL-AP-10-T1 554312	12264668
Sub-base VMPAL-AP-10-T135 554315	12264670
Sub-base VMPAL-AP-10-T135-RV 8035233	14086225
Sub-base VMPAL-AP-10-T1-RV 8035231	14086226
Sub-base VMPAL-AP-10-T35 554313	12264669
Sub-base VMPAL-AP-10-T35-RV 8035232	14086228
Sub-base VMPAL-AP-14 560973	13682683
Sub-base VMPAL-AP-14-QS1/4"-1 561007	14164258
Sub-base VMPAL-AP-14-QS1/4"-1-T1 561031	14164256
Sub-base VMPAL-AP-14-QS1/4"-2 561008	14164271
Sub-base VMPAL-AP-14-QS1/4"-2-T1 561032	14164269
Sub-base VMPAL-AP-14-QS5/16"-1 561001	14164262
Sub-base VMPAL-AP-14-QS5/16"-1-T1 561025	14164260
Sub-base VMPAL-AP-14-QS5/16"-2 561002	14164275
Sub-base VMPAL-AP-14-QS5/16"-2-T1 561026	14164273
Sub-base VMPAL-AP-14-QS6-1 560995	14164259
Sub-base VMPAL-AP-14-QS6-1-T1 561019	14164257
Sub-base VMPAL-AP-14-QS6-2 560996	14164272
Sub-base VMPAL-AP-14-QS6-2-T1 561020	14164270
Sub-base VMPAL-AP-14-QS8-1 560989	14164263
Sub-base VMPAL-AP-14-QS8-1-T1 561013	14164261
Sub-base VMPAL-AP-14-QS8-2 560990	14525938
Sub-base VMPAL-AP-14-QS8-2-T1 561014	14164274
Sub-base VMPAL-AP-14-RV 8034557	14164234
Sub-base VMPAL-AP-14-T1 560975	14164218
Sub-base VMPAL-AP-14-T135 560979	14164216
Sub-base VMPAL-AP-14-T135-RV 8034560	14164231
Sub-base VMPAL-AP-14-T1-RV 8034558	14164233
Sub-base VMPAL-AP-14-T35 560977	14164217

Disclaimer: The content of this document has been composed with the utmost care. However, it is possible that certain information changes over time, becomes inaccurate or incomplete. ERIKS does not guarantee that the information provided on this document is up to date, accurate and complete; the information provided is not intended to be advice. ERIKS shall never be liable for damage resulting from the use of the information provided.

Description	Article
Sub-base VMPAL-AP-14-T35-RV 8034559	14164232
Sub-base VMPAL-AP-20 560974	14164223
Sub-base VMPAL-AP-20-QS10-1 560991	14164277
Sub-base VMPAL-AP-20-QS10-1-T1 561015	14164276
Sub-base VMPAL-AP-20-QS10-2 560992	14164285
Sub-base VMPAL-AP-20-QS10-2-T1 561016	14164284
Sub-base VMPAL-AP-20-QS3/8"-1 561003	14164279
Sub-base VMPAL-AP-20-QS3/8"-1-T1 561027	14164278
Sub-base VMPAL-AP-20-QS3/8"-2 561004	14164287
Sub-base VMPAL-AP-20-QS3/8"-2-T1 561028	14164286
Sub-base VMPAL-AP-20-QS5/16"-1 561009	14164268
Sub-base VMPAL-AP-20-QS5/16"-1-T1 561033	14164267
Sub-base VMPAL-AP-20-QS5/16"-2 561010	14164283
Sub-base VMPAL-AP-20-QS5/16"-2-T1 561034	14164282
Sub-base VMPAL-AP-20-QS8-1 560997	14164266
Sub-base VMPAL-AP-20-QS8-1-T1 561021	14164265
Sub-base VMPAL-AP-20-QS8-2 560998	14164281
Sub-base VMPAL-AP-20-QS8-2-T1 561022	14164280
Sub-base VMPAL-AP-20-RV 8034561	14164239
Sub-base VMPAL-AP-20-T1 560976	14164222
Sub-base VMPAL-AP-20-T135 560980	14164219
Sub-base VMPAL-AP-20-T135-RV 8034564	14164236
Sub-base VMPAL-AP-20-T1-RV 8034562	14164238
Sub-base VMPAL-AP-20-T35 560978	14164221
Sub-base VMPAL-AP-20-T35-RV 8034563	14164237
Sub-base VMPAL-AP-4X10 560981	12265236
Sub-base VMPAL-AP-4X10-QS1/4"-1 561095	14164320
Sub-base VMPAL-AP-4X10-QS1/4"-2 561096	14164325
Sub-base VMPAL-AP-4X10-QS4-1 561089	14164318
Sub-base VMPAL-AP-4X10-QS4-2 561090	14164321
Sub-base VMPAL-AP-4X10-QS6-1 561083	14164319
Sub-base VMPAL-AP-4X10-QS6-2 561084	14164322
Sub-base VMPAL-AP-4X14 560983	14164253
Sub-base VMPAL-AP-4X14-QS1/4"-1 561103	14164323
Sub-base VMPAL-AP-4X14-QS1/4"-2 561104	14164328
Sub-base VMPAL-AP-4X14-QS5/16"-1 561097	14164326
Sub-base VMPAL-AP-4X14-QS5/16"-2 561098	14164330
Sub-base VMPAL-AP-4X14-QS6-1 561091	14164324
Sub-base VMPAL-AP-4X14-QS6-2 561092	14164329
Sub-base VMPAL-AP-4X14-QS8-1 561085	14164327
Sub-base VMPAL-AP-4X14-QS8-2 561086	14164332

Disclaimer: The content of this document has been composed with the utmost care. However, it is possible that certain information changes over time, becomes inaccurate or incomplete. ERIKS does not guarantee that the information provided on this document is up to date, accurate and complete; the information provided is not intended to be advice. ERIKS shall never be liable for damage resulting from the use of the information provided.