



## FESTO Limit switch attachment SRAP

### Characteristics

Series: SRAP

Description	Article
Sensor box SRAP-M-CA1-270-1-A-T2P20 570527	12266365
Sensor box SRAP-M-CA1-270-1-A-T2P20-EX2 570528	12267908
Sensor box SRAP-M-CA1-BB270-1-A-TP20 568236	12267886
Sensor box SRAP-M-CA1-BB270-1-A-TP20-EX2 568237	12267887
Sensor box SRAP-M-CA1-GR270-1-A-T2P20 568246	12267894
Sensor box SRAP-M-CA1-GR270-1-A-T2P20-EX2 568247	12267895
Sensor box SRAP-M-CA1-GR270-1-A-TM20 568238	12267888
Sensor box SRAP-M-CA1-GR270-1-A-TP20 568239	12267889
Sensor box SRAP-M-CA1-GR270-1-A-TP20-EX2 568241	12267890
Sensor box SRAP-M-CA1-YB270-1-A-TM20 568242	12267891
Sensor box SRAP-M-CA1-YB270-1-A-TP20 568243	12267892
Sensor box SRAP-M-CA1-YB270-1-A-TP20-EX2 568245	12267893

Disclaimer: The content of this document has been composed with the utmost care. However, it is possible that certain information changes over time, becomes inaccurate or incomplete. ERIKS does not guarantee that the information provided on this document is up to date, accurate and complete; the information provided is not intended to be advice. ERIKS shall never be liable for damage resulting from the use of the information provided.