

BOSCH Jigsaws



Nominal power consumption	Stroke	Lost motion stroke rate	Cutting depth	Article
W	mm	1/min	mm	
650	26	500 - 3100	90	12216015
780	26	500 - 3100		11963405
800	26	800 - 3000		12558641
800	26	800 - 3000		12558640
				12224927
				12033396
				12212968

Disclaimer: The content of this document has been composed with the utmost care. However, it is possible that certain information changes over time, becomes inaccurate or incomplete. ERIKS does not guarantee that the information provided on this document is up to date, accurate and complete; the information provided is not intended to be advice. ERIKS shall never be liable for damage resulting from the use of the information provided.