



FESTO Flow sensor SFAH

Characteristics

Series: SFAH

Description	Article
Flow sensor SFAH-0.1U-Q4S-PNLK-PNVBA-L1 8058461	14168008
Flow sensor SFAH-0.1U-Q4S-PNLK-PNVBA-M8 8058462	14168012
Flow sensor SFAH-0.5U-Q4S-PNLK-PNVBA-L1 8058463	14168007
Flow sensor SFAH-0.5U-Q4S-PNLK-PNVBA-M8 8058464	14168011
Flow sensor SFAH-100U-G14FS-PNLK-PNVBA-M8 8058476	14168014
Flow sensor SFAH-100U-Q8S-PNLK-PNVBA-L1 8058474	14168002
Flow sensor SFAH-100U-Q8S-PNLK-PNVBA-M8 8058475	14168010
Flow sensor SFAH-10U-Q6S-PNLK-PNVBA-L1 8058469	14168004
Flow sensor SFAH-1U-Q4S-PNLK-PNVBA-L1 8058465	14168006
Flow sensor SFAH-1U-Q4S-PNLK-PNVBA-M8 8058466	13407374
Flow sensor SFAH-200U-G14FS-PNLK-PNVBA-M8 8058479	14168013
Flow sensor SFAH-200U-Q8S-PNLK-PNVBA-L1 8058477	14168001
Flow sensor SFAH-200U-Q8S-PNLK-PNVBA-M8 8058478	14168009
Flow sensor SFAH-50U-G18FS-PNLK-PNVBA-M8 8058473	14410343
Flow sensor SFAH-50U-Q8S-PNLK-PNVBA-L1 8058471	14168003
Flow sensor SFAH-50U-Q8S-PNLK-PNVBA-M8 8058472	13389090
Flow sensor SFAH-5U-Q6S-PNLK-PNVBA-L1 8058467	14168005
Flow sensor SFAH-5U-Q6S-PNLK-PNVBA-M8 8058468	13682895

Disclaimer: The content of this document has been composed with the utmost care. However, it is possible that certain information changes over time, becomes inaccurate or incomplete. ERIKS does not guarantee that the information provided on this document is up to date, accurate and complete; the information provided is not intended to be advice. ERIKS shall never be liable for damage resulting from the use of the information provided.