



FESTO Flow sensor SFAM

Characteristics

Series: SFAM

Description	Article
Flow sensor SFAM-62-1000L-M-2SA-M12 564930	11858986
Flow sensor SFAM-62-1000L-M-2SV-M12 564932	11858987
Flow sensor SFAM-62-1000L-TG12-2SA-M12 565375	11858992
Flow sensor SFAM-62-1000L-TG12-2SV-M12 565376	11859013
Flow sensor SFAM-62-3000L-M-2SA-M12 564934	11858988
Flow sensor SFAM-62-3000L-M-2SV-M12 564936	11858989
Flow sensor SFAM-62-3000L-TG12-2SA-M12 565379	11859014
Flow sensor SFAM-62-3000L-TG12-2SV-M12 565380	11859015
Flow sensor SFAM-62-5000L-M-2SA-M12 564938	11858990
Flow sensor SFAM-62-5000L-M-2SV-M12 564940	11858991
Flow sensor SFAM-62-5000L-TG12-2SA-M12 565383	11859016
Flow sensor SFAM-62-5000L-TG12-2SV-M12 565384	11859017
Flow sensor SFAM-90-10000L-M-2SA-M12 573348	12267911
Flow sensor SFAM-90-10000L-M-2SV-M12 573349	12267912
Flow sensor SFAM-90-10000L-TG112-2SA-M12 573354	12267917
Flow sensor SFAM-90-10000L-TG112-2SV-M12 573355	12267918
Flow sensor SFAM-90-15000L-M-2SA-M12 573350	12267913
Flow sensor SFAM-90-15000L-M-2SV-M12 573351	12267914
Flow sensor SFAM-90-15000L-TG112-2SA-M12 573356	12267919
Flow sensor SFAM-90-15000L-TG112-2SV-M12 573357	12267920
Flow sensor SFAM-90-5000L-M-2SA-M12 573346	12266746
Flow sensor SFAM-90-5000L-M-2SV-M12 573347	12266747
Flow sensor SFAM-90-5000L-TG1-2SA-M12 573352	12267915
Flow sensor SFAM-90-5000L-TG1-2SV-M12 573353	12267916

Disclaimer: The content of this document has been composed with the utmost care. However, it is possible that certain information changes over time, becomes inaccurate or incomplete. ERIKS does not guarantee that the information provided on this document is up to date, accurate and complete; the information provided is not intended to be advice. ERIKS shall never be liable for damage resulting from the use of the information provided.