

FISCHER Door stopper TS



Description	Article
Deurstopper TS 8 wit	23935398
Deurstopper TS 8 grijs	23935397
Deurstopper ass. TS	23935395
Deurstopper TS 8 bruin	23935400
Deurstopper TS 8 zwart	23935399

Disclaimer: The content of this document has been composed with the utmost care. However, it is possible that certain information changes over time, becomes inaccurate or incomplete. ERIKS does not guarantee that the information provided on this document is up to date, accurate and complete; the information provided is not intended to be advice. ERIKS shall never be liable for damage resulting from the use of the information provided.