

## **TELEMECANIQUE Mushroom heads for latching pushbuttons**

Description	Article
Emergency Stop Push Button 22mm Red Mushroom 40mm Turn to release	TQZB5AS844
Emergency Stop Switch Push Button 22mm Red Mushroom 40mm Ronis 421E Key release	TQZB4BS94412
Emergency Stop Switch Push Button 22mm Red Mushroom 60mm Ronis 455 Key release	TQZB4BS964
Harmony <sup>®</sup> Style 4 Mushroom Type Latching Pushbutton Head ZB4BS864	TQZB4BS864
Harmony® Style 4 Mushroom Type Latching Pushbutton Head ZB4BT84	TQZB4BT84
Harmony <sup>®</sup> Style 4 Mushroom Type Latching Pushbutton Head ZB4BT2	TQZB4BT2
Harmony® Style 4 Mushroom Type Latching Pushbutton Head ZB4BS844	TQZB4BS844
Harmony® Style 4 Mushroom Type Latching Pushbutton Head ZB4BS52	TQZB4BS52
Harmony® Style 4 Mushroom Type Latching Pushbutton Head ZB4BS62	TQZB4BS62
Harmony® Style 4 Mushroom Type Latching Pushbutton Head ZB4BS55	TQZB4BS55
Harmony® Style 4 Mushroom Type Latching Pushbutton Head ZB4BS834	TQZB4BS834
Harmony® Style 4 Mushroom Type Latching Pushbutton Head ZB4BS72	TQZB4BS72
Harmony® Style 4 Mushroom Type Latching Pushbutton Head ZB4BS944	TQZB4BS944

Disclaimer: The content of this document has been composed with the utmost care. However, it is possible that certain information changes over time, becomes inaccurate or incomplete. ERIKS does not guarantee that the information provided on this document is up to date, accurate and complete; the information provided is not intended to be advice. ERIKS shall never be liable for damage resulting from the use of the information provided.

Page 1/1

