

TELEMECANIQUE Pushbutton and switch bodies

Description	Article
Flap for Push button Padlockable Red	TQZB4BZ64
Guard for 40mm Emergency Stop Push button Round Yellow	TQZB4BZ1905
Harmony [®] Style 4 Pushbutton Body Assembly ZB4BZ103	TQZB4BZ103
Harmony [®] Style 4 Pushbutton Body Assembly ZB4BZ101	TQZB4BZ101
Harmony [®] Style 4 Pushbutton Body Assembly ZB4BZ104	TQZB4BZ104
Harmony [®] Style 4 Pushbutton Body Assembly Zb4Bz105	TQZB4BZ105
Harmony [®] Style 4 Pushbutton Body Assembly ZB4BZ102	TQZB4BZ102

e e a e o a eointo a PR1461326484095_EN_02.05.2024 incomplete. ERIKS does not guarantee that the information provided on this document is up to date, accurate and complete; the information provided is not intended to be advice.

ERIKS shall never be liable for damage resulting from the use of the information provided.

Disclaimer: The content of this document has been composed with the utmost care. However, it is possible that certain information changes over time, becomes inaccurate or

