

## GRUNDFOS Accessories for CR series multistage pumps



### Characteristics

**Series:** CR/CRN

**Type:** CRN

Description	Article
BUBE Shaft Seal Kit For CR/CRN Size 2/4	GRU405096
BUBE Shaft Seal Kit For CR/CRN Size 30/60	GRU345180
BUBV Shaft Seal Kit For CR/CRN Size 8/16	GRU425063
BUBV Shaft Seal Kit For CR/N Size 2/4	GRU405097
HQQE Shaft Seal Kit For CR/CRN Size 32/45/64/90	GRU96525458
HQQE Shaft Seal Kit For CR/I/N CRE/IE/NE Size 1S,1,3,5	GRU96455086
Wear Parts Kit for CR/I/N CRE/IE/NE Size 1 Stages: 36	GRU96455094
Wear Parts Kit for CR/I/N CRE/IE/NE Size 10 Stages: 22	GRU96511925
Wear Parts Kit for CR/I/N CRE/IE/NE Size 10 Stages: 27	GRU96511922
Wear Parts Kit for CR/I/N CRE/IE/NE Size 10 Stages: 8	GRU96511889
Wear Parts Kit for CR/I/N CRE/IE/NE Size 15/20 Stages:	GRU96511827
Wear Parts Kit for CR/I/N CRE/IE/NE Size 15/20 Stages: 6	GRU96511824
Wear Parts Kit for CR/I/N CRE/IE/NE Size 1S/1/3 Stages: 19	GRU96455092
Wear Parts Kit for CR/I/N CRE/IE/NE Size 1S/1/3 Stages: 7	GRU96455093
Wear Parts Kit for CR/I/N CRE/IE/NE Size 1S/1/3 Stages: 9	GRU96455095
Wear Parts Kit for CR/I/N CRE/IE/NE Size 20 Stages: 17	GRU96511830
Wear Parts Kit for CR/I/N CRE/IE/NE Size 32 Stages: 1 to 2	GRU96416728
Wear Parts Kit for CR/I/N CRE/IE/NE Size 32 Stages: 14	GRU96416731
Wear Parts Kit for CR/I/N CRE/IE/NE Size 32 Stages: 3 to 7	GRU96416729
Wear Parts Kit for CR/I/N CRE/IE/NE Size 32 Stages: 8 to 11	GRU96416730
Wear Parts Kit for CR/I/N CRE/IE/NE Size 45 Stages: 1 to 2	GRU96416732
Wear Parts Kit for CR/I/N CRE/IE/NE Size 45 Stages: 7	GRU96416733
Wear Parts Kit for CR/I/N CRE/IE/NE Size 45 Stages: 8 to 10	GRU96416734
Wear Parts Kit for CR/I/N CRE/IE/NE Size 5 Stages: 10	GRU96455096
Wear Parts Kit for CR/I/N CRE/IE/NE Size 5 Stages: 16	GRU96455098
Wear Parts Kit for CR/I/N CRE/IE/NE Size 5 Stages: 22	GRU96455099
Wear Parts Kit for CR/I/N CRE/IE/NE Size 5 Stages: 26	GRU96455101
Wear Parts Kit for CR/I/N CRE/IE/NE Size 5 Stages: 36	GRU96455100
Wear Parts Kit for CR/I/N CRE/IE/NE Size 64 Stages: 1 to 2	GRU96416735
Wear Parts Kit for CR/I/N CRE/IE/NE Size 64 Stages: 8	GRU96416736
Wear Parts Kit for CR/I/N CRE/IE/NE Size 90 Stages: 1 to 2	GRU96416737
Wear Parts Kit for CR/I/N CRE/IE/NE Size 90 Stages: 3 to 6	GRU96416738
Wear Parts Kit for CR/I/N Size 5 Stages: 12	GRU96455097
Chamber Stack For CR90-2-2 Vertical Multistage with Mechanical Seal	GRU96416258
Chamber Stack For CRN45-2-2 Vertical Multistage with Mechanical Seal	GRU96416241
Chamber Stack For CRI15-7 Vertical Multistage with Mechanical Seal	GRU96491748
Shaft seal kit for CR CRN 8/16 AUUE Tungsten Carbide EPDM	GRU985204
Chamber Stack For CRN32-10 Vertical Multistage with Mechanical Seal	GRU96416301
Chamber Stack For CRI10-8 Vertical Multistage with Mechanical Seal	GRU96491701
Chamber Stack For CRI20-6 Vertical Multistage with Mechanical Seal	GRU96491777
Wear Parts Kit for CRN4-6	GRU415289
Chamber Stack For CR64-3-1 Vertical Multistage with Mechanical Seal	GRU96416313

Disclaimer: The content of this document has been composed with the utmost care. However, it is possible that certain information changes over time, becomes inaccurate or incomplete. ERIKS does not guarantee that the information provided on this document is up to date, accurate and complete; the information provided is not intended to be advice. ERIKS shall never be liable for damage resulting from the use of the information provided.