MAKITA Jigsaw Cordless type



Description	Article
	,
Jigsaw 18V DJV182ZJ without battery/charger, with Mbox	12683019
Jig saw DJV182RTJ LXT 18V 2x5,0Ah	13015795

Disclaimer: The content of this document has been composed with the utmost care. However, it is possible that certain information changes over time, becomes inaccurate or incomplete. ERIKS does not guarantee that the information provided on this document is up to date, accurate and complete; the information provided is not intended to be advice. ERIKS shall never be liable for damage resulting from the use of the information provided.

PR1579278045768546_EN_19.05.2024