



FESTO Flow sensor SFAB

Characteristics

Series: SFAB

Description	Article
Flow sensor SFAB-1000U-HQ10-2SA-M12 565405	12267861
Flow sensor SFAB-1000U-HQ10-2SV-M12 565406	12267862
Flow sensor SFAB-1000U-HQ12-2SA-M12-EX2 565409	12267865
Flow sensor SFAB-1000U-WQ10-2SA-M12 565407	12267863
Flow sensor SFAB-1000U-WQ10-2SV-M12 565408	12267864
Flow sensor SFAB-10U-HQ6-2SA-M12 565385	12265724
Flow sensor SFAB-10U-HQ6-2SV-M12 565386	12265725
Flow sensor SFAB-10U-WQ6-2SA-M12 565387	12265726
Flow sensor SFAB-10U-WQ6-2SV-M12 565388	12265727
Flow sensor SFAB-200U-HQ10-2SA-M12 565397	12265736
Flow sensor SFAB-200U-HQ10-2SV-M12 565398	12265737
Flow sensor SFAB-200U-HQ8-2SA-M12 565393	12265732
Flow sensor SFAB-200U-HQ8-2SV-M12 565394	12265733
Flow sensor SFAB-200U-WQ10-2SA-M12 565399	12265738
Flow sensor SFAB-200U-WQ10-2SV-M12 565400	12265739
Flow sensor SFAB-200U-WQ8-2SA-M12 565395	12265734
Flow sensor SFAB-200U-WQ8-2SV-M12 565396	12265735
Flow sensor SFAB-50U-HQ6-2SA-M12 565389	12265728
Flow sensor SFAB-50U-HQ6-2SV-M12 565390	12265729
Flow sensor SFAB-50U-WQ6-2SA-M12 565391	12265730
Flow sensor SFAB-50U-WQ6-2SV-M12 565392	12265731
Flow sensor SFAB-600U-HQ10-2SA-M12 565401	12265740
Flow sensor SFAB-600U-HQ10-2SV-M12 565402	12265741
Flow sensor SFAB-600U-WQ10-2SA-M12 565403	12265742
Flow sensor SFAB-600U-WQ10-2SV-M12 565404	12265743

Disclaimer: The content of this document has been composed with the utmost care. However, it is possible that certain information changes over time, becomes inaccurate or incomplete. ERIKS does not guarantee that the information provided on this document is up to date, accurate and complete; the information provided is not intended to be advice. ERIKS shall never be liable for damage resulting from the use of the information provided.