



FESTO Flow sensor SFAW

Characteristics

Series: SFAW

Description	Article
Flow sensor SFAW-100-CS520-E-PNLK-PNVBA-M12 8036885	13206633
Flow sensor SFAW-100T-CS520-E-PNLK-PNVBA-M12 8036886	13206634
Flow sensor SFAW-100-TG1-E-PNLK-PNVBA-M12 8036877	13206627
Flow sensor SFAW-100-TG34-E-PNLK-PNVBA-M12 8036875	13206625
Flow sensor SFAW-100T-TG1-E-PNLK-PNVBA-M12 8036878	13206628
Flow sensor SFAW-100T-TG34-E-PNLK-PNVBA-M12 8036876	13206626
Flow sensor SFAW-100T-X-E-PNLK-PNVBA-M12 8036890	13206638
Flow sensor SFAW-100-X-E-PNLK-PNVBA-M12 8036889	13206637
Flow sensor SFAW-32-CS515-E-PNLK-PNVBA-M12 8036883	13206631
Flow sensor SFAW-32-S13-E-PNLK-PNVBA-M12 8036879	13206629
Flow sensor SFAW-32T-CS515-E-PNLK-PNVBA-M12 8036884	13206632
Flow sensor SFAW-32-TG12-E-PNLK-PNVBA-M12 8036871	13206621
Flow sensor SFAW-32-TG34-E-PNLK-PNVBA-M12 8036873	13206623
Flow sensor SFAW-32T-S13-E-PNLK-PNVBA-M12 8036880	13206630
Flow sensor SFAW-32T-TG12-E-PNLK-PNVBA-M12 8036872	13206622
Flow sensor SFAW-32T-TG34-E-PNLK-PNVBA-M12 8036874	13206624
Flow sensor SFAW-32T-X-E-PNLK-PNVBA-M12 8036888	13206636
Flow sensor SFAW-32-X-E-PNLK-PNVBA-M12 8036887	13206635

Disclaimer: The content of this document has been composed with the utmost care. However, it is possible that certain information changes over time, becomes inaccurate or incomplete. ERIKS does not guarantee that the information provided on this document is up to date, accurate and complete; the information provided is not intended to be advice. ERIKS shall never be liable for damage resulting from the use of the information provided.