



## FESTO Pressure sensor SPAU

### Characteristics

Series: SPAU

| Description                                                 | Article  |
|-------------------------------------------------------------|----------|
| Pressure sensor SPAU-B2R-T-R18M-L-PNLK-PNVBA-M8D 8001207    | 14165566 |
| Pressure sensor SPAU-P10R-F-Q4-L-PNLK-PNVBA-M12 8001224     | 14165567 |
| Pressure sensor SPAU-P10R-F-Q6-L-PNLK-PNVBA-M12 8001225     | 13146481 |
| Pressure sensor SPAU-P10R-F-T532-L-PNLK-PNVBA-M12 8001226   | 13146482 |
| Pressure sensor SPAU-P10R-H-G18FD-L-PNLK-PNVBA-M12U 8001220 | 13146483 |
| Pressure sensor SPAU-P10R-H-Q4D-LK-A-M12D 8003350           | 13146485 |
| Pressure sensor SPAU-P10R-H-Q4D-LK-V-M12D 8003349           | 13146486 |
| Pressure sensor SPAU-P10R-H-Q4D-L-PNLK-PNVBA-M12D 8001212   | 13146487 |
| Pressure sensor SPAU-P10R-H-Q4D-L-PNLK-PNVBA-M8D 8001211    | 13146488 |
| Pressure sensor SPAU-P10R-H-T532D-L-PNLK-PNVBA-M12D 8001216 | 13146489 |
| Pressure sensor SPAU-P10R-H-T532D-L-PNLK-PNVBA-M8D 8001215  | 13146490 |
| Pressure sensor SPAU-P10R-MS6-F-L-PNLK-PNVBA-M12D 8074906   | 14165599 |
| Pressure sensor SPAU-P10R-T-G18M-LK-A-M12D 8003346          | 13146491 |
| Pressure sensor SPAU-P10R-T-G18M-L-PNLK-PNVBA-M12D 8001204  | 13146493 |
| Pressure sensor SPAU-P10R-T-N18M-L-PNLK-PNVBA-M12D 8001205  | 13146497 |
| Pressure sensor SPAU-P10R-T-N18M-L-PNLK-PNVBA-M8D 8001202   | 13146498 |
| Pressure sensor SPAU-P10R-T-R14M-L-PNLK-PNVBA-M12D 8001208  | 13146503 |
| Pressure sensor SPAU-P10R-T-R14M-L-PNLK-PNVBA-M8D 8001209   | 13146507 |
| Pressure sensor SPAU-P10R-T-R18M-L-PNLK-PNVBA-M12D 8001206  | 13146513 |
| Pressure sensor SPAU-P10R-T-R18M-L-PNLK-PNVBA-M8D 8001203   | 13146517 |
| Pressure sensor SPAU-P10R-W-G18FD-L-PNLK-PNVBA-M12U 8001230 | 13146522 |
| Pressure sensor SPAU-P10R-W-Q4D-L-PNLK-PNVBA-M12D 8001236   | 13146535 |
| Pressure sensor SPAU-P10R-W-Q4D-L-PNLK-PNVBA-M8D 8001237    | 13146539 |
| Pressure sensor SPAU-P16R-H-G18FD-L-PNLK-PNVBA-M12U 8001222 | 13146544 |
| Pressure sensor SPAU-P16R-T-R14M-L-PNLK-PNVBA-M8D 8001210   | 13146549 |
| Pressure sensor SPAU-V1R-F-Q4-L-PNLK-PNVBA-M12 8001227      | 13146555 |
| Pressure sensor SPAU-V1R-F-Q6-L-PNLK-PNVBA-M12 8001228      | 13146556 |
| Pressure sensor SPAU-V1R-F-T532-L-PNLK-PNVBA-M12 8001229    | 13146557 |
| Pressure sensor SPAU-V1R-H-Q4D-LK-A-M12D 8003352            | 13146559 |
| Pressure sensor SPAU-V1R-H-Q4D-LK-V-M12D 8003351            | 13146560 |
| Pressure sensor SPAU-V1R-H-Q4D-L-PNLK-PNVBA-M12D 8001214    | 13146561 |
| Pressure sensor SPAU-V1R-H-Q4D-L-PNLK-PNVBA-M8D 8001213     | 13146562 |
| Pressure sensor SPAU-V1R-H-T532D-L-PNLK-PNVBA-M12D 8001218  | 13146563 |
| Pressure sensor SPAU-V1R-H-T532D-L-PNLK-PNVBA-M8D 8001217   | 13146564 |
| Pressure sensor SPAU-V1R-T-G18M-LK-A-M12D 8003348           | 13146565 |
| Pressure sensor SPAU-V1R-T-G18M-LK-V-M12D 8003347           | 13146566 |
| Pressure sensor SPAU-V1R-W-G18FD-L-PNLK-PNVBA-M8U 8001235   | 13143867 |
| Pressure sensor SPAU-V1R-W-Q4D-L-PNLK-PNVBA-M12D 8001238    | 13146568 |
| Pressure sensor SPAU-V1R-W-Q4D-L-PNLK-PNVBA-M8D 8001239     | 14165565 |
| SPAU-P10R-T-G18M-LK-V-M12D 8003345 - pressure sensor        | 13146492 |
| SPAU-P2R-W-G18FD-L-PNLK-PNVBA-M8U - pressure sensor         | 13146554 |
| SPAU-P10R-T-G18M-L-PNLK-PNVBA-M8D - pressure sensor         | 13146495 |
| SPAU-P6R-W-G18FD-L-PNLK-PNVBA-M8U - pressure sensor         | 13143855 |

Disclaimer: The content of this document has been composed with the utmost care. However, it is possible that certain information changes over time, becomes inaccurate or incomplete. ERIKS does not guarantee that the information provided on this document is up to date, accurate and complete; the information provided is not intended to be advice. ERIKS shall never be liable for damage resulting from the use of the information provided.

| Description                                          | Article  |
|------------------------------------------------------|----------|
| SPAU-V1R-W-G18FD-L-PNLK-PNVBA-M12U - pressure sensor | 13146567 |
| SPAU-B2R-H-G18FD-L-PNLK-PNVBA-M8U - pressure sensor  | 13146480 |
| SPAU-P10R-W-G18FD-L-PNLK-PNVBA-M8U - pressure sensor | 13146530 |
| SPAU-P10R-H-G18FD-L-PNLK-PNVBA-M8U - pressure sensor | 13146484 |
| SPAU-V1R-H-G18FD-L-PNLK-PNVBA-M8U - pressure sensor  | 13146558 |

Disclaimer: The content of this document has been composed with the utmost care. However, it is possible that certain information changes over time, becomes inaccurate or incomplete. ERIKS does not guarantee that the information provided on this document is up to date, accurate and complete; the information provided is not intended to be advice. ERIKS shall never be liable for damage resulting from the use of the information provided.