



FESTO Pressure sensor SPAW

Characteristics

Series: SPAW

Description	Article
Pressure sensor SPAW-B11R-G12M-2NA-M12 8022822	13146569
Pressure sensor SPAW-B11R-G12M-2N-M12 8022768	14165587
Pressure sensor SPAW-B11R-G12M-2NV-M12 8022840	13146570
Pressure sensor SPAW-B11R-G12M-2PA-M12 8022786	14165597
Pressure sensor SPAW-B11R-G12M-2P-M12 8022750	14165590
Pressure sensor SPAW-B11R-G12M-2PV-M12 8022804	14165596
Pressure sensor SPAW-B11R-G14F-2NA-M12 8022813	13146571
Pressure sensor SPAW-B11R-G14F-2N-M12 8022759	14165588
Pressure sensor SPAW-B11R-G14F-2NV-M12 8022831	14165595
Pressure sensor SPAW-B11R-G14F-2PA-M12 8022777	13146572
Pressure sensor SPAW-B11R-G14F-2P-M12 8022741	13145446
Pressure sensor SPAW-B11R-G14F-2PV-M12 8022795	13146573
Pressure sensor SPAW-B2R-G12M-2NA-M12 8022821	13146574
Pressure sensor SPAW-B2R-G12M-2N-M12 8022767	13146575
Pressure sensor SPAW-B2R-G12M-2NV-M12 8022839	13146576
Pressure sensor SPAW-B2R-G12M-2PA-M12 8022785	13146577
Pressure sensor SPAW-B2R-G12M-2P-M12 8022749	13146579
Pressure sensor SPAW-B2R-G12M-2PV-M12 8022803	13146580
Pressure sensor SPAW-B2R-G14F-2NA-M12 8022812	13146581
Pressure sensor SPAW-B2R-G14F-2N-M12 8022758	14165589
Pressure sensor SPAW-B2R-G14F-2NV-M12 8022830	13146582
Pressure sensor SPAW-B2R-G14F-2PA-M12 8022776	13146583
Pressure sensor SPAW-B2R-G14F-2P-M12 8022740	14165591
Pressure sensor SPAW-B2R-G14F-2PV-M12 8022794	13146584
Pressure sensor SPAW-P100R-G12M-2NA-M12 8022829	13146585
Pressure sensor SPAW-P100R-G12M-2N-M12 8022775	14165568
Pressure sensor SPAW-P100R-G12M-2NV-M12 8022847	13146586
Pressure sensor SPAW-P100R-G12M-2PA-M12 8022793	13146587
Pressure sensor SPAW-P100R-G12M-2P-M12 8022757	14165581
Pressure sensor SPAW-P100R-G12M-2PV-M12 8022811	13146588
Pressure sensor SPAW-P100R-G14F-2NA-M12 8022820	13146589
Pressure sensor SPAW-P100R-G14F-2N-M12 8022766	14165573
Pressure sensor SPAW-P100R-G14F-2NV-M12 8022838	13146590
Pressure sensor SPAW-P100R-G14F-2PA-M12 8022784	13146591
Pressure sensor SPAW-P100R-G14F-2P-M12 8022748	14165584
Pressure sensor SPAW-P100R-G14F-2PV-M12 8022802	13146593
Pressure sensor SPAW-P10R-G12M-2NA-M12 8022825	13146594
Pressure sensor SPAW-P10R-G12M-2NV-M12 8022843	13146595
Pressure sensor SPAW-P10R-G12M-2PA-M12 8022789	13146596
Pressure sensor SPAW-P10R-G12M-2P-M12 8022753	13146597
Pressure sensor SPAW-P10R-G12M-2PV-M12 8022807	13146598
Pressure sensor SPAW-P10R-G14F-2NA-M12 8022816	13146599
Pressure sensor SPAW-P10R-G14F-2N-M12 8022762	14165578

Disclaimer: The content of this document has been composed with the utmost care. However, it is possible that certain information changes over time, becomes inaccurate or incomplete. ERIKS does not guarantee that the information provided on this document is up to date, accurate and complete; the information provided is not intended to be advice. ERIKS shall never be liable for damage resulting from the use of the information provided.

Description	Article
Pressure sensor SPAW-P10R-G14F-2NV-M12 8022834	13146600
Pressure sensor SPAW-P10R-G14F-2PA-M12 8022780	13146601
Pressure sensor SPAW-P10R-G14F-2P-M12 8022744	13146603
Pressure sensor SPAW-P10R-G14F-2PV-M12 8022798	13146604
Pressure sensor SPAW-P16R-G12M-2NA-M12 8022826	13146605
Pressure sensor SPAW-P16R-G12M-2N-M12 8022772	13146606
Pressure sensor SPAW-P16R-G12M-2NV-M12 8022844	13146607
Pressure sensor SPAW-P16R-G12M-2PA-M12 8022790	13146608
Pressure sensor SPAW-P16R-G12M-2P-M12 8022754	13146609
Pressure sensor SPAW-P16R-G12M-2PV-M12 8022808	13146610
Pressure sensor SPAW-P16R-G14F-2NA-M12 8022817	13146611
Pressure sensor SPAW-P16R-G14F-2N-M12 8022763	14165577
Pressure sensor SPAW-P16R-G14F-2NV-M12 8022835	13146613
Pressure sensor SPAW-P16R-G14F-2PA-M12 8022781	13146614
Pressure sensor SPAW-P16R-G14F-2P-M12 8022745	13146615
Pressure sensor SPAW-P16R-G14F-2PV-M12 8022799	13146617
Pressure sensor SPAW-P25R-G12M-2NA-M12 8022827	13146619
Pressure sensor SPAW-P25R-G12M-2N-M12 8022773	14165570
Pressure sensor SPAW-P25R-G12M-2NV-M12 8022845	13146620
Pressure sensor SPAW-P25R-G12M-2PA-M12 8022791	13146621
Pressure sensor SPAW-P25R-G12M-2P-M12 8022755	14165583
Pressure sensor SPAW-P25R-G12M-2PV-M12 8022809	13146622
Pressure sensor SPAW-P25R-G14F-2NA-M12 8022818	13146623
Pressure sensor SPAW-P25R-G14F-2N-M12 8022764	14165576
Pressure sensor SPAW-P25R-G14F-2NV-M12 8022836	13146624
Pressure sensor SPAW-P25R-G14F-2PA-M12 8022782	13146625
Pressure sensor SPAW-P25R-G14F-2P-M12 8022746	13146626
Pressure sensor SPAW-P25R-G14F-2PV-M12 8022800	13146627
Pressure sensor SPAW-P2R-G12M-2NA-M12 8022823	13146628
Pressure sensor SPAW-P2R-G12M-2N-M12 8022769	14165572
Pressure sensor SPAW-P2R-G12M-2NV-M12 8022841	13146629
Pressure sensor SPAW-P2R-G12M-2PA-M12 8022787	13146630
Pressure sensor SPAW-P2R-G12M-2P-M12 8022751	13146631
Pressure sensor SPAW-P2R-G12M-2PV-M12 8022805	13146632
Pressure sensor SPAW-P2R-G14F-2NA-M12 8022814	13146633
Pressure sensor SPAW-P2R-G14F-2N-M12 8022760	14165580
Pressure sensor SPAW-P2R-G14F-2NV-M12 8022832	13146634
Pressure sensor SPAW-P2R-G14F-2PA-M12 8022778	14165594
Pressure sensor SPAW-P2R-G14F-2P-M12 8022742	13146635
Pressure sensor SPAW-P2R-G14F-2PV-M12 8022796	13146636
Pressure sensor SPAW-P50R-G12M-2NA-M12 8022828	13146638
Pressure sensor SPAW-P50R-G12M-2N-M12 8022774	14165569
Pressure sensor SPAW-P50R-G12M-2NV-M12 8022846	13146639
Pressure sensor SPAW-P50R-G12M-2PA-M12 8022792	13146640
Pressure sensor SPAW-P50R-G12M-2P-M12 8022756	14165582
Pressure sensor SPAW-P50R-G12M-2PV-M12 8022810	13146641
Pressure sensor SPAW-P50R-G14F-2NA-M12 8022819	13146642
Pressure sensor SPAW-P50R-G14F-2N-M12 8022765	14165575
Pressure sensor SPAW-P50R-G14F-2NV-M12 8022837	13146643
Pressure sensor SPAW-P50R-G14F-2PA-M12 8022783	13146644
Pressure sensor SPAW-P50R-G14F-2P-M12 8022747	14165585
Pressure sensor SPAW-P50R-G14F-2PV-M12 8022801	13146645
Pressure sensor SPAW-P6R-G12M-2NA-M12 8022824	13146646

Disclaimer: The content of this document has been composed with the utmost care. However, it is possible that certain information changes over time, becomes inaccurate or incomplete. ERIKS does not guarantee that the information provided on this document is up to date, accurate and complete; the information provided is not intended to be advice. ERIKS shall never be liable for damage resulting from the use of the information provided.

Description	Article
Pressure sensor SPAW-P6R-G12M-2N-M12 8022770	14165571
Pressure sensor SPAW-P6R-G12M-2NV-M12 8022842	13146647
Pressure sensor SPAW-P6R-G12M-2PA-M12 8022788	13146648
Pressure sensor SPAW-P6R-G12M-2P-M12 8022752	13146649
Pressure sensor SPAW-P6R-G12M-2PV-M12 8022806	13146650
Pressure sensor SPAW-P6R-G14F-2NA-M12 8022815	13146651
Pressure sensor SPAW-P6R-G14F-2N-M12 8022761	14165579
Pressure sensor SPAW-P6R-G14F-2NV-M12 8022833	13146652
Pressure sensor SPAW-P6R-G14F-2PA-M12 8022779	14165593
Pressure sensor SPAW-P6R-G14F-2P-M12 8022743	13146653
Pressure sensor SPAW-P6R-G14F-2PV-M12 8022797	13146654

Disclaimer: The content of this document has been composed with the utmost care. However, it is possible that certain information changes over time, becomes inaccurate or incomplete. ERIKS does not guarantee that the information provided on this document is up to date, accurate and complete; the information provided is not intended to be advice. ERIKS shall never be liable for damage resulting from the use of the information provided.