



FESTO Filter regulator MS6

Characteristics

Series: MS6

Function: Filter-Regulator

With pressure gauge: Yes

Bowl Material: PC

Lockable: Yes

Housing material: Aluminium die-cast

Size	Port thread type	Port Size	Filtration level	Drain type	Flow direction	Maximum operating pressure	Adjustment range	Flow rate	Weight	Article
		in	µm					l/min	g	
6	BSPP (G)	1/4	40	Automatic	left ? right			2800	875	11645739
6	BSPP (G)	1/4	5	Automatic	left ? right			2200	875	11645743
6	BSPP (G)	1/4	40	Automatic	left ? right			2500	875	11645747
6	BSPP (G)	1/4	40	Manual	left ? right			2500	875	11645745
6	BSPP (G)	1/4	40	Manual	left ? right			2800	875	11645737
6	BSPP (G)	1/4	5	Manual	left ? right			2700	875	11645733
6	BSPP (G)	1/4	5	Manual	left ? right			2200	875	11645741
6	BSPP (G)	1/4	5	Manual	right ? left			2200	875	11645742
6	BSPP (G)	3/8	5	Automatic	left ? right			3500	875	11645762
6	BSPP (G)	3/8	40	Automatic	left ? right			4000	875	11645765
6	BSPP (G)	3/8	40	Automatic	left ? right			4000	1087	11645769
6	BSPP (G)	3/8	5	Automatic	left ? right			3500	1087	11646265
6	BSPP (G)	3/8	5	Automatic	left ? right	12	0.3 - 7 bar	5000	875	11559770
6	BSPP (G)	3/8	40	Automatic	left ? right			5700	875	11645758
6	BSPP (G)	3/8	5	Automatic	right ? left			5000	875	11645755
6	BSPP (G)	3/8	5	Manual	left ? right			3500	875	11645760
6	BSPP (G)	3/8	5	Manual	left ? right			5000	875	11645753
6	BSPP (G)	3/8	40	Manual	left ? right			5700	875	11645756
6	BSPP (G)	3/8	40	Manual	left ? right			4000	875	23212337
6	BSPP (G)	3/8	40	Manual	left ? right			4000	1087	11645767
6	BSPP (G)	1/2	5	Automatic	left ? right			4000	1087	11646257
6	BSPP (G)	1/2	40	Automatic	left ? right			6200	875	11645720
6	BSPP (G)	1/2	40	Automatic	left ? right			4500	1087	11645731
6	BSPP (G)	1/2	5	Automatic	left ? right			5600	875	11645716
6	BSPP (G)	1/2	5	Automatic	left ? right			4000	875	11645724
6	BSPP (G)	1/2	40	Automatic	left ? right			4500	875	11645727
6	BSPP (G)	1/2	40	Automatic	right ? left			6200	875	11645721
6	BSPP (G)	1/2	5	Automatic	right ? left			4000	875	11645725
6	BSPP (G)	1/2	40	Automatic	right ? left			4500	875	11645728
6	BSPP (G)	1/2	5	Manual	left ? right			5600	875	11645714
6	BSPP (G)	1/2	5	Manual	left ? right			4000	875	11645722
6	BSPP (G)	1/2	40	Manual	left ? right			4500	1087	11645729
6	BSPP (G)	1/2	40	Manual	left ? right			6200	875	11645718
6	BSPP (G)	1/2	5	Manual	left ? right			4000	1087	23282861
6	BSPP (G)	1/2	40	Manual	left ? right			4500	875	23211611
6	BSPP (G)	1/2	40	Manual	right ? left			6200	875	11645719
6	BSPP (G)	1/2	40	Manual	right ? left			4500	875	11645726
6	BSPP (G)	1/2	5	Manual	right ? left			5600	875	11645715
6	BSPP (G)	1/2	5	Manual	right ? left			4000	875	11645723

Disclaimer: The content of this document has been composed with the utmost care. However, it is possible that certain information changes over time, becomes inaccurate or incomplete. ERIKS does not guarantee that the information provided on this document is up to date, accurate and complete; the information provided is not intended to be advice. ERIKS shall never be liable for damage resulting from the use of the information provided.